



B021A

Ausgabe Issue 2000-1		Bild Nr. Picture No B021A		SWING 45		SWING 45		Seite Page 8	
Pos. Fig.	Anzahl/Quantity			Artikel Nr. Part No	Bezeichnung	Description	Satz Kit	Anmerkung Notes	
	1			1117-3006-02	Chassie .....	Chassis .....			
	2			1117-3009-01	Radplatte .....	Wheel plate .....			
	3			1117-3010-01	Radplatte .....	Wheel plate .....			
	4			1117-3011-01	Radachse .....	Wheel axle .....			
	5			1111-3238-01	Rad .....	Wheel .....			
X	6			1117-3225-02	Nabenkapsel-weiß .....	Hub cap-white .....			
	7			1117-3007-01	Leitschiene-vordere .....	Baffle-front .....			
X	8			1117-3223-01	Ansatzbolzen .....	Shoulder bolt .....			
X	9			1117-3224-02	Nabenkapsel-weiß .....	Hub cap-white .....			
	10			1117-1161-01	Radschutz .....	Wheel protection .....			
	11			1117-3008-01	Leitschiene-hintere .....	Baffle-rear .....			
	12	14		9836-9516-12	Schraube .....	Screw .....			
	13			1117-1156-02	Klappe-schwarz .....	Rear flap-black .....			
	14			1117-1143-01	Achse .....	Shaft .....			
	15			1117-1126-01	Feder .....	Spring-rear flap .....			
	16			1117-1155-02	Klapphalterung-schw. ....	Flap holder-black .....			
	17			1117-1135-02	• Deckel-schwarz .....	• Cover-black .....			
	18			9987-5251-12	Schraube .....	Screw .....			
	19			1117-1065-01	Tellerfeder .....	Spring washer .....			
	20			1111-3163-01	Rad .....	Wheel .....			
	21			1117-3012-01	Lagerbuchse .....	Wheel bush .....			
	22			1117-1364-01	Schraube .....	Screw .....			
X	23			9600-0014-00	Keil .....	Key .....			
	24			1111-9703-01	Messer .....	Blade .....			
	25			1117-1131-01	Mutter .....	Nut .....			
	26			9699-0028-02	Scheibe .....	Flat washer .....			
	27			9898-0845-12	Schraube .....	Screw .....			
	28			1117-3030-01	Montagesatz .....	Assy kit .....			
	29			9579-0008-00	Kabelhalter .....	Cable holder .....			
X	30			1117-3194-01	Verriegelungsrads .....	Locking knob .....			
	31			9799-0831-02	Mutter .....	Nut .....			
	32			1117-1149-01	Führungsholm-Untert. ....	Handle-lower part .....			
	33			1117-1221-01	Führungsholm-Obert. ....	Handle-upper part .....			
	34			1117-1355-01	Schlüssel .....	Socket wrench .....			
	35			1117-1134-01	Motorbremsdraht .....	Engine brake cable .....			
	35			1117-1183-01	Motorbremsdraht .....	Engine brake cable .....			
	36			1117-1157-02	Behälterdeckel-schwar .....	Grassbag cover-black .....			
	37			1117-1218-01	Behälter-Unterteil .....	Lower grass bag .....			
	38			1117-1148-01	Deckel .....	Cap .....			
	39			9948-0640-16	Schraube .....	Screw .....			
	40			9699-0025-02	Scheibe .....	Washer .....			
	41			9595-0258-00	Spannstift .....	Locating pin .....			
X	42			1111-9716-01	Messerhalterung .....	Blade holder .....			
X	43			1117-3221-01	Regulierbügel .....	OPC lever .....			
	44			9997-0830-16	Schraube .....	Screw .....			
	45			9678-0009-02	Schloßscheibe .....	Lock washer .....			
	46			1111-2927-01	Batteriehalter .....	Battery holder .....			
	47			1117-1116-01	Schnurhalter .....	Ropeholder .....			
	48			9799-0631-02	Mutter .....	Nut .....			

Vantage-Motor  
Classic-Motor  
Inkl. 17