



12-4610-73 SWING 33

1
2
4
6
1
0
7
3

<u>Index</u>	<u>Art.N°</u>		<u>Beneunung</u>	<u>Description</u>
1	421112759.01	X	Messer	Blade
2	421112787.02	X	Messerbolzen	Blade bolt
3	421112751.01	X	Messerhaltung	Blade holder
7	421112750.02	X	Untere gehäuse	Lower cover
8	421112929.03	X	Elektromotor Gehäuse	Motor cover
9	421112761.02	X	Deckel	Flap
10	421112789.01	X	Feder	Spring
11	428369110.12	X	Schraube	Screw
16	421112762.01	X	Rad	Wheel
17	421112763.03	X	Radkappe	Hub cap
18	421112754.01	X	Rad	Wheel
19	421112755.03	X	Radkappe	Hub cap
20	421112756.03	X	Nabenkappe	Wheel cap
21	421112788.01	X	Ansatzschraube	Shoulder bolt
27	424000240.00	X	Kondensator	Condensor (800W Motor)
28	421112765.00	X	Scheibe	Washer
32	421112760.02	X	Grasfangvorrichtung	Collector
33	421112758.02	X	Grasfangvorr. (Oberteil)	Top collector
34	42111.2764.01	X	Gehäuse	Cover
37	421112768.02	X	Führungsholm (Unterteil)	Handlebar tube
38	421112904.02	X	Führungsholm (Oberteil)	Upper handle
39	428467910.16	X	Schraube	Screw
40	425790008.00	X	Kabelhalter	Cable holder